



ACO DRAINAGE TO BE INSTALLED HERE AT THE FOOTPATH. IT IS TO SPAN THE ENTIRE WIDTH OF DRIVEWAY.