



- ① Cut edge to be removed and no sharp edges left on sawn area.
- ② Round top pin kerb
- ③ Square top pin kerb

