





Consumer Unit is currently located in H.
 The plan is to locate the batteries in H,
 space permitting, but if there is insufficient
 space, they will be located in I.